
















A33






mlin za kafu_1 kom
 aparat za espresso_1 kom
 električna cediljka za agrume_1 kom
 toster_1 kom
 mikrotalasna pečnica_1 kom
 električni šporet_1 kom

ledomat_1kom
 jednodelna sudopera_1kom
 kuhinjski bojler_1kom
 mašina za pranje čaša_1kom
 frižider_2 kom

neutralni sto 216+130/70/85_1 kom
 neutralni sto 60/70/85_1 kom
 radna ploča 216+250/70_1 kom
 radna ploča 195/70_1 kom



kuhinjski ormaric 120 kuhinjski ormaric 120



A34

mlin za kafu_1 kom
 aparat za espresso_1 kom
 električna cediljka za agrume_1 kom
 toster_1 kom

ledomat_1kom
 jednodelna sudopera_1kom
 kuhinjski bojler_1kom
 mašina za pranje čaša_1kom
 frižider_1 kom

neutralni sto 130/70/85_1 kom
 radna ploča 190+130/70_1 kom
 radna ploča 60/70_1 kom
 kuhinjski ormaric 120/40/65_2 kom